790T Fuse Box



01- Pre-heat Relay

02- Start Relay

03- Cut Off Hydraulic Oil Valve Fuse

04- Generator Fuse

05- Front Horn Fuse

06- Reverse Alarm Fuse

07- Alternate Fuse

08- Windshield Wiper Fuse

09- Instrument Panel Fuse

10- Working Lights Fuse

11- Alternate Fuse

12- Hot Wind Fuse

13- Turn Signal Light Fuse

14- Alarm Light Fuse

15- Inner Cab Light Fuse

16- Starting Fuse

17- Pre-heat Fuse

18- Air Conditioner Fuse

19- Windshield Wiper Relay

20- Buzzer Relay

21- Turn Signal Light Relay